

RR BRINK LOCKING SYSTEMS

R.R. Brink locks are constructed with quality materials and careful workmanship. They are thoroughly tested prior to shipment and, when received, should be in perfect condition.

Correct door and frame preparation <u>and</u> installation are of paramount importance for our locks to function properly. Electromechanical lock installations require more care than conventional mechanical models. We urge that the following points be read and followed so as to achieve trouble free performance.

<u>DO NOT</u> put foreign objects or lubricants into any R.R. Brink security hardware.

<u>DO NOT</u> close and lock door without electrical or mechanical operation in place to reopen.

<u>DO NOT</u> abuse, mangle, or distort proper operation in any way.

If R.R. Brink hardware is returned for repair showing evidence of abuse during installation a charge for repair or replacement will be passed onto the contractor.

If problems do exist during installation, call R.R. Brink for assistance.

<u>PLEASE NOTE</u>: Installation instructions specific to the item of hardware are at the beginning of each hardware section in this manual.